

Parts List — SMS5088

Part Number	Description	Config Step	Qty
250877	MANUAL, OPERATORS – SMS TOOLBAR	Configuration Type	1
400001	ASSY, HYD MANIFOLD - WINGS	Configuration Type	1
400003	ASSY, HYD MANIFOLD - OPENERS - SMS	Configuration Type	1
601207	CTN, HYD - WING/OPENER - MAIN FRAME - SMS	Configuration Type	1
602510	KIT, HARNESS - TOOLBAR CLEARANCE LIGHTS - E-SERIES	Configuration Type	1
TBD	ASSY, 9012W-5 PLEX-SMS	Opener Spacing	1
421091	ASSY,SMS KNIFE-1/2IN	Opener Spacing	90
255130	PACKER TIRE - OTICO - V - FARMFLEX -BLACK - 420 X 100MM - TIRE-IN-TIRE	Opener Spacing	90
405456	BDL, HIGH FLOAT TIRES - 5 PLEX	Rear Wing Tires	1
490405	BDL, REAR AXLE - MAIN FRAME - CT AND M-FOLD - 380/55R16.5 - STAGE 1	Rear Axle Options	1
451541	BDL, RVN - TXB - TBT CART - STAGE 2	Control System Configuration	1
270162	KIT, IN-CAB - CR7 - STAGE 1	In Cab Control Options - Toolbar Only	1
254516	HITCH, ARTICULATING BALL - BULL PULL - CAT 5 - STAGE 1	Front Hitch	1
502095	BDL, WALKWAY - FRONT HITCH - STAGE 1	Add-On Toolbar Options	1