

## Parts List — SR5008

Part Number	Description	Config Step	Qty
250876	MANUAL, OPERATORS – SR - STAGE 1	Configuration Type	1
419000	S/L, SINGLE RANK SR6015 - LIQUID ON BOARD	Tank Configuration	1
270225	SCALE, DIGITAL - HANDHELD	Tank Configuration	1
419095-1	BDL, RESIDUE WHEEL - SPLIT BUSHI 6015 SR - STAGE 3	Tank Configuration	1
419096	BDL, OPENER HOSE HOLDERS SB - SR	Tank Configuration	1
419200	BDL, LIQUID CRADLE /W 2150 TANK - SR ON FRAME - STAGE 1	Tank Configuration	1
419205	BDL, SR LIQUID - PUMP/VALVE MNT - STAGE 2	Tank Configuration	1
TBD	Agtron Legend Blockage	Tank Configuration	1
419271	BDL, OPENERS - SR6015 - STD	Opener Configuration	1
400529	BDL, FERT KNIFE SR	Fertilizer Knife Option	48
419440	BDL, DISTRIBUTION - LIQUID FERTILIZER - 48 RUN - 4 ZONE - SR - STAGE 3	Liquid Nozzle Flow Rate	1
419238	ASSY, LIQUID BOOM - 4 OUTLET - YELLOW VR SINGLE BARB NOZZLE 10-50 US GAL. - STAGE 3	Liquid Nozzle Flow Rate	2
402889	ASSY, LIQUID BOOM - 5 OUTLET - YELLOW VR SINGLE BARB NOZZLE 10-50 US GAL. - STAGE 3	Liquid Nozzle Flow Rate	2
402888	ASSY, LIQUID BOOM - 7 OUTLET - YELLOW VR SINGLE BARB NOZZLE 10-50 US GAL. - STAGE 3	Liquid Nozzle Flow Rate	2
402897	ASSY - LIQUID BOOM - 8 OUTLET - YELLOW VR SINGLE BARB NOZZLE 10-50 GAL. - STAGE 3	Liquid Nozzle Flow Rate	2

Part Number	Description	Config Step	Qty
260862	KIT, LIQUID SECTION CONTROL - 4 ZONE - VIPER 4+ - LIQUID SR - STAGE 2	Liquid Nozzle Flow Rate	1
404140	BDL, LIQUID DROP TUBE	Liquid Nozzle Flow Rate	48
270132	KIT, IN-CAB - VIPER 4+ - No GPS	Raven Monitor	1
270155	CODE, UNLOCK VIPER 4 COMBO VRA (SINGLE+MULTI)	VRA Unlock Code	1
451144-1	BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2	Remote Tank Monitor	1
412713	ASSY, CAN ROLL-UII-12W/CLAMPS	Bottom Meter - Canola Roller	8
417056-1	CTN, HYD - FRONT HITCH EXTENSION KIT - SR15	Front Hitch Hose Extensions	1
419400	BDL, HITCH - REAR - SR15 - STAGE 1	Rear Hitch Option	1