

## Parts List — SR5096

Part Number	Description	Config Step	Qty
250876	MANUAL, OPERATORS	Configuration Type	1
417000	BDL, SINGLE RANK SR6015	Tank Configuration	1
270225	SCALE, DIGITAL - HANDHELD	Tank Configuration	1
419095-1	BDL, RESIDUE WHEEL - SPLIT BUSHI 6015 SR - STAGE 3	Tank Configuration	1
419096	BDL, OPENER HOSE HOLDERS SB - SR	Tank Configuration	1
400532	BDL, HD FERT KNIFE - SR	Tank Configuration	1
419271	BDL, OPENERS - SR6015 - STD	Opener Configuration	1
419264	BDL, LIQUID SR - PWM W/ HYPRO PUMP MNT	Liquid Control	1
419440	BDL, DISTRIBUTION - LIQUID FERTILIZER - 48 RUN - 4 ZONE - SR - STAGE 3	Liquid Nozzle Flow Rate	1
419234	ASSY, LIQUID BOOM - 4 OUTLET - BLUE VR SINGLE BARB NOZZLE 15 - 72 U.S. GAL - STAGE 3	Liquid Nozzle Flow Rate	2
402912	ASSY, LIQUID BOOM - 5 OUTLET - BLUE VR SINGLE BARB NOZZLE 15 - 72 U.S. GAL - STAGE 3	Liquid Nozzle Flow Rate	2
402898	ASSY, LIQUID BOOM - 7 OUTLET - BLUE VR SINGLE BARB NOZZLE 15-72 U.S. GAL. - STAGE 3	Liquid Nozzle Flow Rate	2
402904	ASSY, LIQUID BOOM - 8 OUTLET BLUE VR SINGLE BARB NOZZLE 15-72 U.S. GAL - STAGE 3	Liquid Nozzle Flow Rate	2
260862	KIT, LIQUID SECTION CONTROL - 4 ZONE - VIPER 4+ - SR w/ TBH LIQUID CART	Liquid Nozzle Flow Rate	1
419245	BDL, RVN - LIQUID CONTROL - RCM ADD ON - W/ PANEL - SR	Liquid Nozzle Flow Rate	1

Part Number	Description	Config Step	Qty
404140	BDL, LIQUID DROP TUBE	Liquid Nozzle Flow Rate	48
270132	KIT, IN-CAB - VIPER 4+ - No GPS	Raven Monitor	1
270155	CODE, UNLOCK VIPER 4 COMBO VRA (SINGLE+MULTI)	VRA Unlock Code	1
451144-1	BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2	Remote Tank Monitor	1
412712	ASSY,STD ROLLER CARTRIDGE	Top Meter - Standard Roller	5
417056-1	CTN, HYD - FRONT HITCH EXTENSION KIT - SR15	Front Hitch Hose Extensions	1
419400	BDL, HITCH - REAR - SR15 - STAGE 1	Rear Hitch Option	1