

## Parts List — UP5002

---

Part Number	Description	Config Step	Qty
250875	MANUAL, OPERATORS	Configuration Type	1
410102	BDL, BAGLIFTER - UPII350/360 - 530 - BASE LEVEL - STAGE 1	Baglift	1