

## Parts List — UP5020

Part Number	Description	Config Step	Qty
250875	MANUAL, OPERATORS	Configuration Type	1
480750	BDL, DISTRIBUTION - ULTRAPRO II - 80 RUN - 10 ZONE - DUAL PRODUCT	Tank Size	1
412303	BDL, STRAP - C/W SIDE RELEASE BUCKLE - STAGE 2	Tank Size	80
412670	BDL, DELIVERY WING HOSE HOLDER - SHORT - STAGE 2	Tank Size	6
412671	BDL, DELIVERY WING HOSE HOLDER - MEDIUM - STAGE 2	Tank Size	12
418202	BDL, TARP, ELECTRIC ADD ON - UPII 530 - STAGE 2	Electric Tarp Add On	1
410103	BDL, BAGLIFTER - UPII 530 - STAGE 1	Baglift	1
418003	BDL, ULTRAPRO II - 530 BU - 10 ZONE - WIDE M	Tank Configuration	1
270225	SCALE, DIGITAL - HANDHELD	Tank Configuration	1
451144-1	BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2	Tank Configuration	1
412140-3	ASSY, CANOLA ROLLER CARTRIDGE - UPII - 8 RUN - STAGE 2	Tank Configuration	10
412100-3	ASSY, STANDARD ROLLER CARTRIDGE - UPII - 8 RUN	Tank Configuration	10
412103-3	ASSY, STANDARD ROLLER CARTRIDGE - UPII - 8 RUN - W/ CLAMPS - STAGE 2	Tank Configuration	10
TBD	Agtron Legend Blockage - 8012 - 10 Zone	Blockage Installation	1