

## Parts List — UP5061

---

Part Number	Description	Config Step	Qty
250875	MANUAL, OPERATORS	Configuration Type	1
414009	BDL, ULTRAPRO II - 550 BU - 8 ZONE - WIDE M	Tank Configuration	1
270225	SCALE, DIGITAL - HANDHELD	Tank Configuration	1
451144-1	BDL, SEEDBDL, SEEDMASTER, REMOTE TANK MONITOR - STAGE 2	Tank Configuration	1