

Parts List — UP5097

Part Number	Description	Config Step	Qty
250875	MANUAL, OPERATORS	Configuration Type	1
A510320	WELD, DUAL PRODUCT BOOT - SEED ROW - STD - BLK	Configuration Type	1
A510330	WELD, DUAL PRODUCT BOOT - SEED ROW - MIR - BLK	Configuration Type	1